

Winterizing the Alde System:

1. Located in the heating system area (where the hot & cold water lines are attached to the heating system) you will find some white (T-stem) pull valves in the water lines.
 - a. Pull up on the T-stem valves, to release and drain the fresh water from the heating unit.
 - b. Once all water has drained from the unit, close all drain lines.
 - c. Add 3 to 4 gallons of RV antifreeze to the fresh water holding tank.
 - d. Open up the cold water faucet in the shower and let it drain until the color of the water matches the color of the RV antifreeze added into the system. Once this occurs, turn off the faucet.
 - e. At sink faucet - Repeat the process above (in step D).
 - f. At hot water tank - Repeat the process above (in step D).

Once the above steps are performed the lines will be full of RV antifreeze and the system is winterized and protected for the winter.

When spring arrives and you are ready to use the unit, flush the system out with fresh water by repeating the process above.

Need RV Antifreeze:

Shop at Wal-Mart? Its house brand, Super Tech RV and Marine Antifreeze, is virgin pure. Likewise is Camco's Easy Going -50 brand.