



FRITZ! WLAN Repeater 310

Connection using the Online Wizard

- Connect the Fritz Repeater on a socket outlet and wait for appr. 2 minutes for rebooting until the Power and WLAN leds go on.
- Using a computer search for available wireless networks and connect with FRITZ!WLAN Repeater 310.
- For first connection with the repeater use "00000000" as the repeater's Network key.
- When the connection is established start a Web browser and type as web page <http://fritz.repeater> or simply type fritz.repeater as shown below.




- Select the willing language, e.g. English and click on Apply.



- After rebooting click "To Overview". **Reconnect with the repeater if the connection is terminated.**




- Type now a new FRITZ!WLAN Repeater Password and click OK.




- Reenter the password for Log in and click Log on.




- Then click Next.




- Select the WLAN Network to connect with and click Next.



- Type the WLAN key of the selected WLAN Network and click Next.



- Click Finish.



Completion of the Configuration has been established. Bare in mind that the FRITZ!WLAN repeater 310 network is no more appeared in the list of WLAN networks but only connection to the selected one.

