




Cable to Actuator Installation




- 1 Insert cable into actuator from the backside of the actuator.




- 2 Rotate cable into position and lower cable into bracket.



- 3 Slide retainer clip forward over bracket and tighten nut.



Cable should be installed as shown for proper operation.



Improper cable installation will prevent the valve from operating correctly.