



Spray Gun Recommended Tip Size Chart

1. Primer Sealers & Adhesion Promoters
1.2, 1.3, 1.4
Air Pressure Start Point: 25 to 30psi
[\(Adjust As Needed\)](#)

2. Primers & High Build Primers
1.4, 1.5, 1.8, 1.9, 2.0
Air Pressure Start Point: 30psi
[\(Adjust As Needed\)](#)

3. Solvent based paints
1.2, 1.3, 1.4
Air Pressure Start Point: 22-28psi
[\(Adjust As Needed\)](#)

4. Water Based Paints
1.4, 1.5
Air Pressure Start Point: 30-40psi
[\(Adjust As Needed\)](#)

5. Clear Coats
1.2, 1.3, 1.4
Air Pressure Start Point: 19-30psi
[\(Adjust As Needed\)](#)

6. Activators
1.3, 1.4, 1.5, 1.8, 1.9
Air Pressure Start Point: 14.5psi
[\(Adjust As Needed\)](#)

Mini Gun Recommended Tip Size Chart

1. Ceramic Coatings
0.5, 0.8
Air Pressure Start Point: 18-22psi (2" Fan at 6-8")
[\(Adjust As Needed\)](#)

2. Solvent Paints and Clears
1.0, 1.2
Air Pressure Start Point: 19-30psi
[\(Adjust As Needed\)](#)