

INSTRUCTIONS for SAFETY and LONG LIFETIME

Within these instructions you will be able to find information to most common questions about correct usage of PLASTOFORM Blanca windows. If you can't find the information you need here, please contact us directly on email: blanca@plastoform.si



WHILE DRIVING

When vehicle is in motion all windows must be fully closed.

SUN BLINDS

Never use blind on direct sunlight. If you use the blind on direct sunlight, also for a shorter period, heat will accumulate between window and blind and window will get damaged (will start bending, ballooning...).

CLEANING

Never use abrasive and corrosive substances or solvents on windows, such as turpentine, spirit, dishwasher detergents, as they will damage acrylic and/or print. We recommend cleaning with generous amount of water or mild cleaner intended for use on acrylic. Every cleaning with dry cloth can damage the acrylic and leave scratches; always use moist sponge or moist soft cloth. Never clean windows with high pressure washer. Also carwash can damage windows and cause scratches or other damages.

Acrylic material can get scratched very easily, please consider above instructions for cleaning, so that you will not cause scratches or other damages while cleaning.



CONDENSATION

Condensation can appear on the window or between both panes. This is a normal occurrence that appears because of different temperatures inside and outside, moist and properties of acrylic itself. Condensation will disperse after some time. This doesn't mean that there is something wrong with the window or that it is leaking. With properly ventilating the vehicle, you can in most cases prevent also condensation.

OPENING AND CLOSING THE WINDOWS

Your windows are equipped with either handles with button or handles without button and stays on step version or in version with knob screw. Consider the following instruction to avoid the most common damages that can occur:

Handles with button: always push the button when opening/closing handle.



Stays in step version: you will hear clicks when opening the window. Every click represents position in which a window can stay opened. When closing the window, you must open it till the end and then close. Do not try to close it without first opening it as wide as it goes, as this will damage the stays.



Stays with knob screw: always make sure to unscrew the knob before closing the window.



Catcher enables three positions of the window. Open position is where the handle is open placed on the outer part of the catcher. If the handle is placed in the middle of the catcher, this is position for ventilating. Closed position is position where the handle is closed on the inner part of the catcher.



1.1 open position



1.2 ventilation



1.3 closed position

Plastoform Blanca windows are top quality windows from acrylic material. If you consider above instructions, your windows can stay in good shape for a long time. Windows also require periodic maintenance and check by your dealer at least once per year.