



S7 Prepare a STAND-BASE ASSY to assemble it.



4.2 Disassembly procedures:

- S1 Remove the STAND-BASE ASS'Y and unscrew the screw on rear cover.

Use a tool (like picture using) to open all latches. Remove the screws to remove the STAND-BASE ASSY.



- S2 Remove the rear cover. Use a tool (like picture using) to open all latches. (Be careful the position of the key board.)

