

How to connect your Palstar LA-1K Amp

# To A Flex 6600M

Parts required are DB-9 female and head shell.

C232HM-EDHSL-0 cable with FTDI chip.

## Wire:

BDC A in pin-2 Orange

BDC B in pin-1 Yellow

BDC C in pin- 9 Green

BDC D in pin- 8 Brown

Ground pin- 6 Black

