



DESIGNED TO MOVE [YOU]®

# JWM20

## QUICK REFERENCE GUIDE

### Basic Operation

**HDMI/AUX:** Press to cycle through HDMI IN and REAR AUX source mode.

**BT/USB:** Press to cycle through BLUETOOTH and USB source mode.


**AM/FM:** Press to cycle through radio source mode.

**VOLUME:** Press the VOLUME UP  $\blacktriangle$  button to increase volume. Press the VOLUME DOWN  $\blacktriangledown$  button to decrease volume.

**POWER/DIM:** Press to turn ON. Press again to switch the DIMMER (On/Off). Hold to turn OFF and enter standby mode.

**BACK:** Press to exit any menu.

**HDMI IN:** Connect HDMI cable from device.



**AUDIO:** Hold to bring up AUDIO ADJUSTMENT options: BASS, TREBLE, BALANCE (left to right), FADE (front to rear), & Loudness (ON/OFF).

**SPEAKER ZONE A:** Press to select speaker zone output.

**SETTINGS:** Hold to bring up SETTING MENU options: BLUETOOTH Device List, BLUETOOTH PAIR, BLUETOOTH (ON/OFF), DIMMING (ON/OFF), DIMMING LEVEL, PRESET VOLUME, TIME (12/24) and RESET. Press  $\blacktriangle$  and  $\blacktriangleright$  buttons to select each SETTING option except for "RESET".

**SPEAKER ZONE B:** Press to select speaker zone output.

**RESET:** Use a ball point pen or thin metal object to press the reset.

### AM/FM Tuner Controls

**AM/FM:** Press to change source to radio mode.

**P.SCAN:** Hold to access Tuner option menu, press again to cycle through AUTO STORE & PRESET SCAN and Press  $\blacktriangleright$  to select.

**AUTO STORE:** Store strongest broadcast station in your area.  
**PRESET SCAN:** Scan through currently stored presets.

**VOLUME:** Press the VOLUME UP  $\blacktriangle$  button to increase volume. Press the VOLUME DOWN  $\blacktriangledown$  button to decrease volume.



**TUNER/SEEK/TRACK:** Press  $\blacktriangleright$  button to tune frequency higher. Press  $\blacktriangleleft$  button to tune frequency lower. Press and hold to scan to next strongest station.

**STATION STORE PRESETS:** Hold to store current station. Press once to recall stored channel. NOTE: Up to 18 FM & 12 AM channels can be stored.

### USB Playback


**MODE:** Press to cycle source to USB mode.

**VOLUME:** Press the VOLUME UP  $\blacktriangle$  button to increase volume. Press the VOLUME DOWN  $\blacktriangledown$  button to decrease volume.

**RANDOM:** Press to play all tracks in random order. Press again for normal playback.

**PLAY/PAUSE:** Press to PAUSE or RESUME current audio.

**REPEAT:** Press consecutively to cycle through (Track, Folder, all) playback of tracks.



**TUNER/SEEK/TRACK:** Press  $\blacktriangleright$  button to advance to NEXT TRACK. Press  $\blacktriangleleft$  button to advance to PREVIOUS TRACK. Press & Hold to fast forward/reverse seek through the track.

**FOLDER DOWN:** Press to go to previous folder.

**FOLDER UP:** Press to go to next folder.

**USB:** Connect a USB flash/thumb drive for audio playback.

## Bluetooth Operation

**MODE:** Press cycle source to BT mode.

### PAIR DEVICE VIA BLUETOOTH:

Make sure the device you intend to pair with is on and Bluetooth is enabled.

Press & hold to start the pairing process. The display will show 'PAIR' and be able to be paired with for 120 seconds. With your device in Bluetooth settings, 'JWM20' should appear as an available device. Tap 'JWM20' to connect.

**VOLUME:** Press the VOLUME UP  $\uparrow$  button to increase volume. Press the VOLUME DOWN  $\downarrow$  button to decrease volume.



**SETTINGS:** Press & hold to navigate through menu options, Press  $\blacktriangleright$  to select BT Device LIST or PAIR.

**TUNER/SEEK/TRACK:** Advance or reverse tracks on your device.

**PLAY/PAUSE:** Press to PAUSE or RESUME current audio.

**ANSWERING PHONE:** BT audio will automatically pause when a call is answered. It will then resume once call has ended. In some cases, it may be necessary to press the play button to resume the BT audio.

## Clock With Alarm

**TIME VIEW:** Press to toggle clock display or song information.

### ALARM/SLEEP TIMER/TIME SET:

Hold to bring up time menu and press again to cycle through the menu options: ALARM (ON/OFF), ALARM SET, SLEEP TIMER (OFF, 0, 15, 30, 45, 60 MINUTES), CLOCK SET. Press  $\blacktriangleright$  button to adjust hour, press  $\blacktriangleleft$  button to adjust minutes either clock or alarm time.

**BACK:** Press to exit time menu.



**TIME (12H/24H):** Hold to bring up SETTING MENU and press repeatedly to cycle through setting menu until TIME (12/24) set reached. Press  $\blacktriangleleft$  and  $\blacktriangleright$  buttons to select 12 hours clock or 24 hours clock.

For owner's manual, please visit <http://www.asaelectronics.com/manuals-guides>.



QRG三折页

P/N:918K30000G

尺寸：165\*230mm

材质：157G铜版纸

工艺：4C印刷，表面过光油

